

How to make a Quilt in a Day Design Wall

Items Required

- | | |
|--|-------------------|
| (2) Spray contact cement | (4) "L" brackets |
| 9' x 5' Headliner from upholstery shop | Box 3/4" screws |
| 4' x 8' Sound Board | Chop Saw |
| Keyhole hooks | Knife or scissors |
| (4) wall anchors with screws | (2) "T" brackets |
| (4) 1" X 4" X 8' pine boards | |

Making the sound board

1. Measure headliner to appropriate length. Allow an extra 4 inches to hang over on each side.
2. Apply the glue thoroughly to soundboard and back of the headliner. Allow 15-20 minutes for the glue to get tacky. It's easier to do halves.
3. When the soundboard is tacky, apply headliner to the soundboard. The headliner will stick immediately on contact. Use your friend to help make sure you have it aligned properly to cover the board with equal edges on all sides. Once the headliner has touched the surface, it may be impossible to re align.
4. Turn project over and apply contact cement the edges where the headliner may touch. Allow 15-20 minutes to insure tact.
5. Fold over the headliner and attach it to the sound wall. Allow the corners to be even.
6. Trim off headliner ears. When laying down the headliner, try to avoid overlapping the edges.

Making the Frame

1. Cut (2) 1" X 4"s into three 40" boards.
2. Attach the 1" X 4" to make a 4' X 8' frame with your "T" brackets and "L" brackets.
3. Apply adhesive caulking to one side of the frame.
4. Press frame to the back of the soundboard. Put weights on the frame to help press it down. (Books, water jugs, etc.) Leave alone until it dry.
5. Screw key hooks to the back frame and to wall where desired.